


Copyright © ICY DOCK International. All Rights Reserved. 650284 VER 1.0

## 1

Package Contents • Packungsinhalt • Contenu • Contenido del paquete • 包装について • 包装説明 • 包装说明



Device



User Manual




8xM3\*2.5 Screws for Device  
(2 x Screws for Spare Parts)

ⓘ Note: Please use the included screws to secure the drive(s).

## 2


Device Information • Geräteinformationen • Informations dispositifif • Información del dispositivo • 本体説明 • 機體説明 • 机体说明

### ▼ Front View



1. Drive Power Buttons / LED Indicator
  - Device Power: Solid Blue Light
  - HDD Access: Flashing Blue Light
2. Drive Ejection Buttons
3. Fan Speed Control (The default setting of fan speed is set to maximum)



### ▼ Rear View





## 3

Installation Guide • Installationsanleitung • Guide d'Installation • Guía de instalación • 製品の組み込み手順について • 操作步驟 • 操作步驟


1. Installing 2.5" Drives - Insert the drive all the way into the slot.




2. Powering on the Drives - Push the drive power buttons inward to power up the drive.



3. Removing 2.5" Drives - Push the drive eject button to eject the drive from the slot. Once the drive is ejected, simply pull on the drive to remove.



Push button to eject drive



ICY DOCK®

www.icydock.com



For the warranty information, please visit [www.icydock.com/warranty.php](http://www.icydock.com/warranty.php)